



## CCTV Block Diagram 66KV to 400KV Class of GETCO Sub-Station



**Special Instruction:** For Sub-station where 11KV system is available, one (01) no. camera to be install to view front side operation activity and one (01) camera to be installed to view back side operation activity.


## CCTV Block Diagram 66KV to 400KV Class of GETCO Sub-Station



**Special Instruction:** For Sub-station where 11KV system is available, one (01) no. camera to be install to view front side operation activity and one (01) camera to be installed to view back side operation activity.

## CCTV Block Diagram 66KV to 400KV Class of GETCO Sub-Station

### 220KV Class Sub-Station Block Diagram



**Special Instruction:** For Sub-station where 11KV system is available, one (01) no. camera to be install to view front side operation activity and one (01) camera to be installed to view back side operation activity.

## CCTV Block Diagram 66KV to 400KV Class of GETCO Sub-Station

### 400KV Class Sub-Station Block Diagram

